


Master Unit Battery Instructions



Follow these steps to install your Master Unit Battery

- 1. Carry the Master Unit Battery to the top of the bin in a backpack or something that allows you to have both hands free to safely climb the bin.
- 2. Install the Master Unit Battery by setting the magnetic feet on the roof of the bin in a place where it's easily accessible. Give enough cord length for the allow the Master Unit to be located on the south side of the bin for maximum solar exposure. If possible, place the Master Unit Battery between two of the ladder rungs near the top of the bin roof.
- 3. Connect the link cable from the Master Unit Battery to the link cable labelled "Power Cable" on the Master Unit.
- 4. Your Master Unit is now powered up, please refer to the User Manual or Quick Start Guide for further installation details.

If you're connecting the Master Unit Battery to an older style master unit with an internal battery, please contact your dealer or IntraGrain support for assistance.